

PLUS

Creative Board CB+ Preparation Guide

This document is the "Preparation Guide" for the Creative Board CB+.

It contains information on:

How to obtain the user manual/Checking included accessories/Component names/Installation instructions/After-sales service

Please store this guide safely after reading.

How to Obtain the User Manual [Important]

The user manual is NOT included in the product packaging.

Before use, scan the QR code below or visit:



<https://www.plus-vision.com/en/product/creativeboard/cbplus/help.html>


Confirmation of Main Unit Packaging

This preparation guide only lists the contents of the main unit package.


For other packages, refer to the instructions included with each package.

The contents of the main unit package are as follows. Please check before use.


• Main unit x1



• Control panel x1 (attaches to main unit)




• Marker tray x1 (attaches to main unit)



• Cable cover x1

(covers USB cable between main unit/control panel)



• Cable clip x1

(secures power USB cable to control panel)




• M4x12 tapping screw x1 (for cable cover)



• M4x40 tapping screw x1 (for control panel)




• Dedicated markers (black/red) x1 each




• 4-sided eraser x1

(rotate sponge pad when dirty)



■ Accessories:

• USB power adapter x1 (*For this product only*)



• Power USB cable x1 (*For this product only*)



Documents:



• Safety precautions x1 (Mandatory reading)

• Preparation guide x1 (this document)


• Warranty card x1

User manual is not included. Please refer to "How to Obtain the Owner's Manual" above.

Component Names



LED Color	System Status	Notes
Off	No power	
Red	Powered off	
Green	Operational	Do not unplug power adapter
Orange	Sleep mode	




Notice:

For connection methods of each port, refer to the Appendix in the Assembly/Installation Manual or User Manual.


● Readable Area Specifications

The scannable range is indicated by the gray-shaded area.
Content drawn outside this area may not be captured during printing/saving.



● Caster Lock/Unlock Mechanism

After installing the unit on the stand:
Lock casters by pressing the lever downward (prevents movement during use).
Unlock casters by pushing the lever upward (enables relocation).



Installation Information

The installation overview and reference manuals are as follows.

Please note that wall installation should be carried out by a professional (fees apply).

Warning

Before installation, please carefully read the separate "Safety Precautions" and install correctly. Incorrect installation may cause fire, injury, or malfunction.

Set Name	Installation Outline	Reference Manual
Main Unit + T-shaped Legs	Assemble the T-shaped legs. Attach the control panel, cable cover, and powder tray to the main unit, and install it on the T-shaped legs.	T-shaped Legs Assembly and Installation Manual
Main Unit + Y-shaped Legs	Assemble the Y-shaped legs. Attach the control panel, cable cover, and powder tray to the main unit, and install it on the Y-shaped legs.	Y-shaped Legs Assembly and Installation Manual
Main Unit + Wall-mount Brackets	Attach the wall-mount brackets to the wall. Attach the control panel, cable cover, and powder tray to the main unit in order, and install it on the wall-mount brackets.	Wall-mount Brackets Assembly and Installation Manual

Notice: For assembly instructions, please refer to the "Assembly and Installation Manual" or the "User Manual."


Stand Installation Notes

caution

- Please carry the main unit with two or more people. Dropping or tipping may cause unexpected injuries.
- Press the lower side of the caster lock lever on the stand to fix the casters. If the stand moves during removal or installation, it may cause unexpected injuries.
- When changing the height of the main unit, unplug the USB power adapter from the wall outlet and disconnect all connection cables from the input/output terminals of the main unit. Removing the main unit while connected may cause the stand to tip over and result in unexpected injuries.
- Press the lower side of the caster lock lever on the stand to fix the casters. If the stand moves during removal or installation, it may cause unexpected injuries.


External view of T-leg set (There is a choice of two installation heights.)

The short end of the T-leg (caster bar) is behind the stand.




External view of Y-leg set (Installation height is fixed at one position.)

The Y-shaped leg without the hook is behind the stand.



Wall Mount Appearance Diagram (Installation height can be fixed at any desired level.)

The diagram shows the wall mount bracket attached to the wall.



caution

- Please use the USB power adapter and USB power cable.
- When taking this product (including accessories) outside of the country, please check the applicable laws such as the Foreign Exchange and Foreign Trade Act, U.S. Export Administration Regulations, and Radio Law.

Maintenance Support Service

If your product is defective, we will repair it according to the following procedure. Please contact your nearest company office, sales company, retailer, or the "Vision Customer Center." For inquiries regarding warranty details, usage, or any unclear points, please also contact your nearest company office, sales company, retailer, or the "Vision Customer Center."

Free Repairs

If the defective product is accompanied by a warranty card with the purchase date and retailer name recorded (within one year from the purchase date), we will repair it free of charge within the scope specified in the warranty card.

*For details, please refer to the product warranty regulations stated in the warranty card.

Paid Repairs

Repairs after the warranty period will generally be charged. Even within the warranty period, the following cases will be charged. Additionally, transportation and other costs will be borne by the customer.

1. When the warranty card is not presented or attached at the time of repair request.
2. When the purchase date and retailer name are not recorded on the warranty card, or if the wording has been altered.
3. Products disassembled or modified by parties other than our company or authorized retailers.
4. Damage or defects caused by natural disasters such as fire, earthquake, or wind and water damage.
5. Defects caused by improper handling (incorrect operation not described in the instruction manual, dropping, impact, water exposure, sand, mud adhesion, water/sand/mud entering the internal mechanism, etc.), improper storage (storage in high temperature and humidity or places containing naphthalene or camphor), or improper maintenance (mold growth).
6. Defects caused by reasons other than those attributable to our company.
7. Special requests for inspections, precision checks, disassembly, and cleaning of parts.

Unrepairable Cases

Products that are severely damaged due to submersion, strong impact, or other reasons, making it impossible to restore their performance to the pre-defect state, or products for which parts are difficult to obtain, may not be repairable.

Please contact your nearest company office, sales company, retailer, or the "Vision Customer Center" for inquiries.

Notes for Repair Requests

1. When requesting repairs under warranty regulations, please be sure to attach the warranty card.
2. Provide detailed explanations of the specified repair locations and defect details.
3. If no repair locations are specified, our company will repair all areas deemed necessary for quality and performance, which may result in higher costs.
4. Remove and keep any accessories unrelated to the repair to prevent loss or other accidents.
5. When transporting the product for repair, pack it securely in the original box or an equivalent box.

Retention Period for Repair Parts

Repair parts for this product will be retained for approximately five years after production is discontinued. Repairs will generally be accepted during this period. If the retention period for parts has expired, please contact your nearest company office, sales company, retailer, or the "Vision Customer Center."

The contents of this document are subject to change without notice.

PLUS Corporation
プラス株式会社